



Limitorque™ MX/QX

HART Field Unit



The HART (Highway Addressable Remote Transducer) Protocol is the global standard for sending and receiving digital information across standard, twisted-pair instrumentation cables connecting smart field devices and control/monitoring systems. This information can be accessible from a technician's hand-held device or laptop connected to a plant's process control, asset management, safety or other system using any control platform.

The HART network employs a bi-directional communication protocol, operating at 1,200 bits/sec that provides data access between intelligent devices such as Limitorque MX and QX electronic actuators and a distributed control system (DCS) or other monitoring systems. In addition to a digital system, the network simultaneously provides a 4-20 mA analog signal that is proportional to the field unit's primary measured value.

Features and Benefits

The following commands and feedback information can be transmitted and received by MX/QX HART unit:

- OPEN, CLOSE and STOP commands
- ESD (emergency shutdown) commands
- Partial stroke test commands
- Go-to-position commands
- Unit output torque (0–100% rating)
- Actuator status, alarm and diagnostic messages
- Burst messages
- Travel histogram
- Event notifications
- LimiGard™ patented signal monitoring
(U.S. Patent No. 5,719,559)




The MX/QX HART field unit interface board is installed in the actuator controls compartment, permitting the actuator to be controlled by a DCS or other network host over the HART network.

Technical Data

The HART protocol is defined as an open network standard. Limitorque MX and QX electronic actuators are certified for use by the HART Communication Foundation (HCF).

The MX/QX HART field unit uses the HART protocol to communicate over the HART network with other HART-enabled devices. The HART protocol is a master/slave communication service for process control devices. HART digital signaling is an extension of conventional analog signaling, allowing the network signal to ride on the 4-20 mA DC process signal. It uses 1,200 bps binary phase-continuous Frequency-Shift-Keying (FSK), where a high-frequency current is superimposed on a low-frequency (typically, 4-20 mA DC) analog current.

HART Protocol — Network Topologies



- Complies with HART Communication Protocol Specification (Document HCF Spec-13) for Revision 7.4
- Point-to-point or multi-drop network topology
- Distances up to 1,800 meters/network (up to 15 devices)
- EDDL (IEC 61804-2, EDDL) with methods for all supported common practice and device-specific commands
- VALVESIGHT DTM for all FDT/DTM-compliant Asset Management Systems
- Device variables: position set point; valve position; torque; compartment/motor temperature
- Universal commands: 0–3, 6–9, 11–22, 38, 48 to read primary variable; loop current; device status, etc.
- Common practice commands: 33, 35–37, 40–42, 45–46, 49–51, 53–54, 56, 59–60, 63, 65–68, 71, 76, 78–79, 89–93, 95, 103–109, 115–119 for calibration; self-test; burst mode; event notification; real-time clock; trending, etc.
- Device-specific commands: partial stroke test; travel histogram; encoder health; LimiGard™; motor controller health; torque settings; software version; network ESD configuration, DO relay control; QX stroke time; operational data, etc.
- Positioning commands: OPEN, CLOSE, STOP; % POSITION

To learn more about Limitorque MX and QX electronic actuators, see LMEMNBR2302 and LMENBR3302, respectively.

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can (and often does) provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation and maintenance of Flowserve products. The purchaser/user should read and understand the Installation Operation Maintenance (IOM) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

© 2014 Flowserve Corporation, Irving, Texas, USA. Flowserve is a registered trademark of Flowserve Corporation.

To find your local Flowserve representative,
visit www.flowserve.com or call:
USA +1 800 225 6989
International +1 972 910 0774

United States
Flowserve Corporation
Limitorque Actuation Systems
5114 Woodall Road
Lynchburg, VA 24506 USA
Telephone: 434 528 4400
Fax: 434 845 9736

FCD LMENFL2340-01-AQ Printed in USA. November 2014 © 2014 Flowserve Corporation.