

Flowserve Corporation
Flow Control Division
www.flowserve.com

1350 N. Mountain Springs Parkway
Springville, Utah 84663-3004
Phone: 801 489 8611

1978 Foreman Dr.
Cookeville, TN 38501
Phone: 931 432 4021

2-Way Visual Indicator Options

Introduction:

Automax visual indicators provide visible position confirmation for “on-off” valve actuators. These indicators feature “green open” and “red closed” color schemes for intuitive viewing.

Our Pharos™ indicator features a snap-on dome sealed against moisture and made from durable polycarbonate material. The Pharos™ is available on all Automax products.

The UltraDome™ indicator is available on our PL Series UltraSwitch™ for maximum chemical resistance. This version is also sealed against moisture and features screw-fastening.



Description:

Automax visual indicators include a black dome with clear windows arranged 180 degrees from one another. A red-and-green rotor, attached to the switch shaft, turns under the dome. Green windows indicate open; red windows indicate closed.

Optional Pharos™ Configuration:

The Pharos™ may also be provided with a gray dome and “yellow closed” and “black open” rotor.

How to Order:

UltraSwitch™ figure numbers include a meaningful character for visual indicator. Referring to the table of contents page and the chart below, simply specify the appropriate character.

Indicator Option	Meaningful Character
2-way Pharos™ red-green indicator	2
2-way Pharos™ yellow-black indicator	G
2-way UltraDome™ red-green indicator for PL Series UltraSwitch™ only	U