

# General Industry Leakage Collection System

# Collect atmospheric leakage and detect seal failure

Reducing emissions into the environment is the top priority for any mechanical seal. Having a system that can collect emissions and detect seal failure can improve environmental impact and reduce maintenance costs.

## A standardized Plan 65 system

The Flowserve N65 leakage collection and detection system is designed for general industry and is used with single mechanical seals on process fluids that condense at ambient atmospheric conditions. Mechanical seal failure can be detected when an excessive flow rate into the system increases the fluid level in the reservoir.

The N65 system has two standard configurations:

- N65A: normal seal leakage passes through an orifice to a drain, while excess leakage collects in the reservoir to be detected by instrumentation
- N65B: normal leakage collects in the reservoir with a closed valve for disposition by maintenance operations

In the event of a seal failure, high liquid level in the reservoir is detected by a level transmitter or switch.


#### **Features and benefits**

- Maximum absolute working pressure (MAWP) 27.6 bar at 149°C (400 psi at 300°F)
- Ambidextrous mounting options for easy installation
- Designed with standard 3 liter (0.79 US gallon) effective volume
- All stainless-steel construction for superior corrosion protection
- Low-cost and easy-to-install standard NPT connections and construction
- Pre-configured switch selections for reduced lead-time
- Designed in accordance with ASME VIII.1 with optional U-stamp
- Optional PED and CRN compliance





## **General Industry Leakage Collection System**



#### Headquarters

Flowserve Corporation 5215 North O'Connor Blvd. Suite 700

Irving, Texas 75039-5421 USA Telephone: +1 937 890 5839

#### **USA** and Canada

Kalamazoo, Michigan USA Telephone: +1 269 381 2650

### Europe, Middle East, Africa

Etten-Leur, The Netherlands Telephone: +31 765 028 200

#### **Asia Pacific**

Singapore

Telephone: +65 6544 6800

#### Latin America

Mexico City

Telephone: +52 55 5567 7170

#### SSFLY000485-00 (EN/A4) March 2022

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful like. However, the purchaser or user of Flowserve products should be aware that Flowserve products in gift be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the Installation Instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

©2022 Flowserve Corporation. All rights reserved. This document contains registered and unregistered trademarks of Flowserve Corporation. Other company, product, or service names may be trademarks or service marks of their respective companies.